

RV & CAMPING APPLIANCES

Essential Appliances	Running Watts	Surge Watts	Kitchen Appliances	Running Watts	Surge Watts	Entertainment Appliances	Running Watts	Surge Watts
4 Light Bulbs (75W)	300 W	300 W	Blender	350 W	500 W	12" B&W TV	30 W	30 W
Dehumidifier	785 W	1250 W	Chest Freezer	450 W	900 W	19" Color TV	160 W	160 W
Electric Blanket	80 W	1,250 W	Coffee Maker	800 W	800 W	27" Color TV	500 W	500 W
Electric Water Heater (6 Gal.)	1,440 W	1,440 W	Corn Popper	275 W	275 W	AM/FM Cassette	10 W	10 W
Fan	200 W	200 W	Crockpot	250 W	250 W	CD/DVD Player	50 W	200 W
Furnace Fan (1/3 HP)	700 W	1,400 W	Deep Fryer	1,200 W	1,200 W	Clock Radio	100 W	100 W
Heating Pad	250 W	250 W	Dorm Size Refrigerator	350 W	500 W	Desktop Computer	600 W	800 W
RV Roof-Top AC (13,500 BTU)	1,500 W	2,000 W	Electric Can Opener	170 W	0 W	Inflator Pump	50 W	50 W
Space Heater	1,800 W	1,800 W	Electric Fry Pan	1,200 W	1,200 W	Laptop	200 W	250 W
Washing Appliances	Running Watts	Surge Watts	Electric Grill	1,650 W	1,650 W	Printer	500 W	500 W
Blow Drier (Hair)	1,250 W	1,250 W	Hot Plate	1,200 W	1,725 W	Radio 2-Way	360 W	960 W
Clothes Washer	1,150 W	2,300 W	Microwave (635W Cooking Power)	635 W	800 W	Satellite Dish & Receiver	30 W	250 W
Curling Iron	800 W	800 W	Slow Cooker	170 W	270 W	Stereo	450 W	450 W
Iron	1,200 W	1,200 W	Toaster	850 - 1,250 W	850 - 1,250 W	VCR	100 W	100 W
Shaver	35 W	35 W	Toaster Oven	1,200 W	1,200 W	https://generatorist.com		
Vacuum	1,100 W	1,100 W	Waffle Iron	1,200 W	1,725 W			